

三久 參考型水份計 攜帶式

SUNCUE MOISTURE REFERENCE METER PORTABLE



TD-6

米麥兩用

測定對象

稻穀、糙米、白米
大麥、小麥、裸麥

PADDY WHEAT
Application
Paddy, Brown Rice,
Polished Rice, Barley,
Wheat, Rye.



VS-6

蔬菜種子

測定對象

油菜籽、辣椒、番茄
茄子、黃瓜、蘿蔔

VEGETABLE SEED
Application
Rapeseed, Chilli,
Tomato, Eggplant,
Cucumber, Radish.



TA-B

黃豆玉米

測定對象

黃豆、玉米

SOYA CORN
Application
Soya, Corn.

清楚易懂、操作簡單

大型液晶顯示清楚易懂，操作按鈕少可防止錯誤發生。

平均值計算機能

只要按平均值按鈕，就可計算2~9次的平均值。

溫度補正機能

採用特殊電子迴路自動溫度補正裝置。

自動斷電機能

經過一分鐘以上沒有操作時，電源會自動切斷。

Clear and easy to understand / Simple operation

Large, easy-to-read LCD display. Simple button design to prevent errors.

Average calculation

Press "average" button to get average moisture content from 2 to 9 entries.

Temperature compensation

Unique electronic circuit can do temperature compensation automatically.

Power off automatically

After one minute without operating, power will shut off automatically.

三久參考型水份計 攜帶式 機能豐富、操作簡單、防止過度乾燥

SUNCUE Moisture Reference Meter Portable - Multiple functions, simple operation, prevents overdrying.

攜帶型收納盒 Portable Case



- ① 小取樣勺 Spoon(S)
 - ② 刷子 Brush
 - ③ 鑷子 Forceps
 - ④ 大取樣勺 Spoon(L)
 - ⑤ 試料盤 Sample Tray
 - ⑥ 電池 Batteries
 - ④ 碾米器 Huller
- TA-B
● TD-6 / VS-6

測定步驟 Measuring Procedures

三機型的測定步驟相同
The same for 3 models.



- ① 按壓**測定**鈕
電源開關
Press **MEASURE** key
power switch



- ② 按壓**選擇**鈕 ▶ 選擇穀物
Press **SELECT** key
▶ to select grains



- ③ 試料盤插入測定部
Insert the sample tray
into measuring part



- ④ 旋轉測定把手
Rotate the handle



- ⑤ 按壓**測定**鈕 · 顯示水份值
Press **MEASURE** key
to display the result

項目Item	機型Model	規格 Specifications					
測定對象及範圍 Application & Measuring Range	TD-6	稻穀 Paddy	8.7~40.0%	糙米 Brown Rice	9.1~40.0%	白米 Polished Rice	9.8~20.0%
		大麥 Barley	8.0~34.3%	小麥 Wheat	8.6~35.0%	裸麥 Rye	8.4~34.7%
	VS-6	油菜籽 Rapeseed	5.5~20.0%	番茄 Tomato	7.8~20.0%	黃瓜 Cucumber	7.2~20.0%
		辣椒 Chilli	5.9~20.0%	茄子 Eggplant	7.1~20.0%	蘿蔔 Radish	4.9~20.0%
	TA-B	黃豆, 玉米 Soya, Corn 9~30%					
顯示解析度 Resolution		0.1% 但是30%以上以1%為量測單位		0.1% Moisture content above 30% will be rounded off to the nearest integer.			
使用溫度範圍 Operating Temp. Range		5~40°C 結露除外		5~40°C Exception for dewing.			
顯示方式 Display		大型L.C.D液晶數字顯示		LCD digital screen			
電源 Power		3號乾電池 1.5V×4入 長時間不使用須移除電池		No.3 "AA" batteries 1.5V×4 units Remove batteries when the meter is not in use.			
本體尺寸 Dimensions		長172×寬100×高75 mm		L172×W100×H75 mm			
重量 Weight		約500g		About 500g			

- 測定注意事項：本水份計是以日本穀物為標準，及採用日本檢量線，會因地區性、大氣溫度、相對濕度、穀物品種之不同，所測得之水份會有誤差。所以請依當地的國家標準，例如絕乾法：5g粉碎的穀物，放入105°C的恆溫箱，烘乾5小時的作業方法，或配合當地糧管單位的水份計和本水份計做出對照表，再施行測定作業，顯示出的水份值再看對照表的實際水份值，即本水份計的穀物含水率是參考值。
- 圖示及規格僅供參考，實際產品規格以客戶簽署訂單及出貨實物為主。
- Notice for Moisture Reference Meter: since the design of TD-6/VS-6/TA-B follows the calibration curve of grain in Japan, the user may obtain different moisture test results because of variables in region, ambient temperature, relative humidity and grain varieties. Please make calibration according to your national standard, such as oven-dry method (drying 5g of ground grain in an oven at 105°C for 5 hours) or make a tabulation by comparing the moisture reading on TD-6/VS-6/TA-B with the standard of local authority to obtain accurate result. Therefore, the moisture content registered on TD-6/VS-6/TA-B is for reference only.
- The specification and graph are for reference only. Actual specification shall be based on the Sales Confirmation which customers sign and delivered products.

SUNCUE
三久股份有限公司
SUNCUE COMPANY LTD.

41278 台中市大里區仁化路105號
No. 105, Renhua Rd., Dali Dist., Taichung City 41278, Taiwan, R.O.C.
☎ +886-4-2339-7171 ☎ +886-4-2330-2939
www.suncue.com
sales@suncue.com



服務中心 Service Center